



Brød & Taylor Shelf Kit Accessory for the Folding Proofer Instruction Manual



Contents

Shelf Kit contains two aluminum hanging rails and one stainless steel rack with fold out legs.

Instructions

1. Set up Proofer, leaving lid aside.
2. Hang the aluminum hanging rails over opposite short walls of the Proofer. The side of the hanging rail with the single opening should be facing the top of the Proofer, and the side of the hanging rail with three cut out notches should be facing down with the tabs pointing to the interior of the Proofer.
3. Close the lid and set thermostat to desired temperature.
4. When Proofer is preheated, first load the lower shelf with pan(s) or jars. Fit the stainless steel rack into the hanging rails so that the rack wires fit into the three cut out notches on the rack. Load the upper rack and replace the lid.
5. For most even results, rotate pans top to bottom about half way through proofing.

Care and Maintenance

Stainless steel rack is dishwasher safe. Aluminum hanging rails can be wiped with a damp cloth or hand washed with soap and water.